


# RESERVDELAR

## SC KK300



Pos.No.	Part No	Description
1	RES-15304	The door body
2	RES-15305	Return hinge
3	RES-15306	Body
4	RES-15307	The upper hinge cover
5	RES-15308	The upper hinge
6	RES-10059	Screw
7	RES-15309	Temperature display device
8	RES-15310	The wind machine plate screw
9	RES-15311	The wind machine plate
10	RES-15312	Air blower
11	RES-15313	Thermostat
12	RES-15314	Thermostat knob
13	RES-15315	Fixing screw
14	RES-15316	Fan baffle reinforced iron
15	RES-15317	Switch
16	RES-15318	Fan shade
17	RES-15319	Lampshade
18	RES-15320	Cabinet lamp
19	RES-15321	On the shelf
20	RES-15322	Lower rack
21	RES-15323	Shelf block set of 4
22	RES-15324	Rack bar
23	RES-15325	Evaporator pad screw
24	RES-15326	Evaporator
25	RES-10128	Fixed Block
26	RES-15327	Wire clamp screw
27	RES-12438	Saddle clamp
28	RES-15328	Cable clamp
29	RES-15329	The power assembly
30	RES-15329	The power assembly
31	RES-10088	Screw
32	RES-10163	Spring washer
33	RES-10162	Washer
34	RES-15330	Sleeve
35	RES-15331	Rubber pad
36	RES-15332	Compressor complete
37	RES-15333	Starter
38	RES-15334	Thermal protector
39	RES-15335	Cable box
40	RES-15336	Fixed line box holder
41	RES-15337	Casters
42	RES-12416	Foot
43	RES-15338	Evaporating pipe
44	RES-13472	Water box
45	RES-10059	Screw
46	RES-15339	Compressor plate
47	RES-15340	Nut
48	RES-15341	External fan support
49	RES-10059	Screw
50	RES-15342	External fan
51	RES-15343	Condenser
52	RES-10059	Screw
53	RES-15344	Dry filter
54	RES-15345	After the protective net
55	RES-10059	Screw
56	RES-15346	The lower hinge
57	RES-10059	Screw
58	RES-15315	Fixing screw
59	RES-15347	Front shield
60	RES-10098	Screw
61	RES-15348	Front shield support
62	RES-15349	AC/DC Power
63	RES-10098	Screw
64	RES-15350	Inside the water box
65	RES-15351	Fixed water box screw
66	RES-15352	screw
67	RES-15353	
68	RES-15354	door lamp
69	RES-15355	Axle sleeve
70	RES-15356	End bar of door
71	RES-15357	Door gasket
72	RES-15358	screw
73	RES-15359	Handle